

Title

License activation

Description

You can activate your dongle by the following steps.

Topics

| | |
|------------------------|---|
| Preparation..... | 2 |
| Enter Ticket ID..... | 3 |
| Activate License | 4 |

Preparation

1. Connect your CodeMeter dongle to USB port of your host PC.
2. Startup dSPACE Installation Manager from start menu.
(Start menu -> dSPACE Installation Manager -> dSPACE Installation Manager)
3. Open your license ticket and copy ticket ID on Ticket Group ID field.

License Overview

Embedded Success

dSPACE

Delivery Date 2018-01-18
Sales Order AU-XXXXXX
Purchase Order JPNXXXXXX

Ticket Group ID ACT-XXXXX-XXXXX-XXXXX-XXXXX-XXXXX


Order Number

Product


Ticket ID

Enter Ticket ID

1. Open "Licensing" tab at the top of the screen.
2. Open "License Administration" tab.
3. Select "License Activation".
4. Click "Next" button.




5. Enter the copied ticket ID in the Ticket ID field on dSPACE Installation Manager.
6. Click "Add" button.



Activate License


Then a list of your license is displayed.

1. Check the license which you want to activate.
2. Click "Next" button.




3. Select "Local access"
4. Select your dongle information.
5. Click "Finish" button.

*If done information does not appear, click "Rescan" button.



[Activate licenses?] will be displayed.

6. Click "Yes(Y)" button.



License activation will be completed when you see the message "License Activation Completed"

